

METRONIC

FREESAT HD SOFTWARE UPGRADE

These instructions will assist you in downloading the software upgrade to the Freesat HD receiver. This information is also available on page 14 of the Instruction manual.

1. Insert a USB stick into the USB slot situated at the back of the receiver between the power cable and the HDMI cable. (If the stick is too wide, remove the HDMI cable and connect the receiver using a scart lead – please note if using the scart lead you will need to change the TV source to AV1 or 2).
2. Select **MENU → SYSTEM → INFORMATION**
3. Select **USB UPGRADE → SELECT SLOT → SELECT USB** - Press OK
4. Select **DRIVE** and after a few seconds Line A will display “Disk 1” – Press OK
5. Select the Highlighted file “**zdx620_freesat_v083.zim**” – Press OK
6. Wait until the reading of the file is completed and when the message “Do you want to update” appears, Select **YES** to perform the software upgrade.
7. Please wait until the Programming Flash process is completed (do not switch off the power or remove the USB device during this process).
8. Reset to default in the **SET DEFAULTS MENU** – Select **YES** to restore to factory default with all current settings and data eliminated or Select **NO** to keep the current data settings.

The USB stick can now be safely removed from the receiver. Once removed turn the receiver onto standby and unplug the power cord before reinserting to reboot the receiver.